

■ Assembly instructions

Tent 10' x 10'

A) Supplied material



- Structure of a tent 10' x 10'
- Carry bags with wheels
- Printed canvas



See video on our channel!
Click here!



B) Assembly of the tent



1. Take out the structure of the carry bag and place it on the ground, on the vertical side.

2. Expand the structure by pulling the posts out.

3. Take out the printed canvas and place it on top of the structure.

Place the four spikes in line with the four legs as well as the center point of the roof.

4. Stretch the structure as far as possible by pulling the posts outwards.

Lift the four legs halfway up, so as to engage the push button in the first hole.

Tighten the roof fabric well, position the valences so as to eliminate all folds.



■ Assembly instructions

Tent 10' x 10'

B) Assembly of the tent (continuing)



5. Place the inner lining of the valance spikes in position above each post.
6. Lift the legs at the second hole and engage the push button to secure them at the maximum height.
7. Repeat the exercise for all the legs in order to obtain the same height for the whole structure.
8. Push the central pole inside the tent upwards and engage the push button.



9. Tie the plastic clips together and tighten the straps to adjust the tension of the canvas.
10. If needed, nails or metal hooks can also be hammered in to secure the tent, when used outdoors, in a location that is windy.

It is also possible to order rubber weights or sandbags to install at the bottom of each leg to stabilize the tent optimally. Contact our sales department for all the details.

